



WIKING Maxi 2



WIKING Maxi 4



WIKING Maxi 6

|           |   |
|-----------|---|
| <b>DK</b> | Montering af friskluftssystem                       |
| <b>EN</b> | Assembly Instructions for Fresh Air System          |
| <b>DE</b> | Einbauanleitung für das Frischluftsystem            |
| <b>SE</b> | Monteringsanvisning för friskluftssystem            |
| <b>NO</b> | Monteringsveiledning for friskluftssystem           |
| <b>NL</b> | Montage-instructies voorhet verseluchtsysteem       |
| <b>FR</b> | Guide d'installation du système à air de combustion |
| <b>IT</b> | Istruzioni per la presa d'aria esterna              |
| <b>ES</b> | Instrucciones de montaje de aire de combustión      |
| <b>FI</b> | Paloilman tuontiputken asennusohje                  |
| <b>PL</b> | Instalacja systemu świeżego powietrza               |
| <b>CS</b> | Instalace systému čerstvého vzduchu                 |



































































